

TAKE-UPS

SCREW TYPE AUXILIARY TAKE-UP (FOR LIVE ROLLERS)



Screw type auxiliary take-ups are the most common take-ups used on models 138VP, 196VP, 638CALR, 796CALR, 196ZPA and 251CALR for additional belt take-up. Live roller model ATS4 shown at left and ATS6 shown below.



SPECIFY MODEL NUMBER PER EXAMPLE

ATS4-33-R
 ATS(pulley diameter*)-(between frames)-
 (live roller type)
 *Specify 4 for model ATS4 with 4" dia. pulleys or 6 for model ATS6 with 6" dia. pulleys.

SPECIFICATIONS

4" AUX. TAKE-UP: (2) 4" dia. pulleys with 1-3/16" dia. shaft, machine crowned.

6" AUX. TAKE-UP: (2) 6" dia. pulleys with 1-7/16" dia. shaft, machine crowned.

FRAME: Depth of (4") 8" x 10 ga. formed steel, Depth of (6") 9-1/2" x 10 ga. formed steel.

TAKE-UP: 24" belt take-up.

BEARINGS: Heavy duty, relubricable, ball bearings with cast iron housings.

MODEL ATS4 FOR LIVE ROLLERS							
BF	15"	19"	21"	25"	27"	33"	39"
WT	105	113	117	125	129	141	153
MODEL ATS6 FOR LIVE ROLLERS							
BF	15"	19"	21"	25"	27"	33"	39"
WT	119	129	135	146	151	167	183

■ 24 hour shipment ■ 2 week shipment